



A NIBE GROUP MEMBER

Startup and Warranty Registration Form (Air Cooled UCR)

Sign, date and E-mail to: technicalsupport@climacoolcorp.com or Fax: 405.815.3000 Attn: Technical Support

Ambient Temp: Page: 1 of 1

Project Name: Address: City/State/Zip: Startup Date:

Contractor Name: Address: City/State/Zip: Phone No:

Module

Model No.: Serial No.: Chiller No.: Bank No.:

Compressor

Model No.: Serial No. 1: Serial No. 2:

Bank Water Pressure Entering / Leaving

Evaporator: / Δ P "Flow devices" shut off chiller below approx 40% loss of flow:

Water Samples Taken: (Mark "X")

Evaporator: Yes N/A Yes

For initial MANDATORY water samples, bottles are provided. Follow instructions on label and mail the same day sample is taken.

- All wiring terminations in module panel, safeties and compressors tightened: Yes No
Rotation of scroll compressor is correct: Yes No

Voltage / Ground

L1 L2 L3 Low Voltage (24V):

Phase / Phase

L1/L2 L2/L3 L1/L3

Compressor Circuit #1

Amperage: L1 L2 L3 Sight Glass Oil Level: Suction Pressure (psig): Suction Temperature (F): Compressor Superheat (F): Discharge Pressure (psig): Discharge Temperature (F): Discharge Gas Superheat (F): Condenser Liquid Line Temperature (F): Condenser Liquid Subcooling Temp (F): Evaporator Entering Water Temp (F): Evaporator Leaving Water Temp. (F): Condenser Entering Air Temp. (F): Condenser Leaving Air Temp. (F): Evaporator Pressure Differential (psig):

Compressor Circuit #2

Amperage: L1 L2 L3 Sight Glass Oil Level: Suction Pressure (psig): Suction Temperature (F): Compressor Superheat (F): Discharge Pressure (psig): Discharge Temperature (F): Discharge Gas Superheat (F): Condenser Liquid Line Temperature (F): Condenser Liquid Subcooling Temp (F): Evaporator Entering Water Temp. (F): Evaporator Leaving Water Temp. (F): Condenser Entering Air Temp. (F): Condenser Leaving Air Temp. (F): Evaporator Pressure Differential (psig): Software Version:

Verify Safety Setting Limits:

Table with 3 columns: Low Temp, High Pressure, Low Pressure

Verify Safety Setting Limits:

Table with 3 columns: Low Temp, High Pressure, Low Pressure

Rep Signature:

Print Name:

E-Signature: Check Box (Authorized Signature)